

Применимость запчасти к автомобилям

Марка	Модель	Двигатель	Год	KW	HP
<u>HONDA</u>	<u>CIVIC VIII Saloon (FD, FA)</u>	<u>1.3 Hybrid (FD3)</u>	1-10 - -	85	116
<u>HONDA</u>	<u>CR-V IV (RM_)</u>	<u>1.6 i-DTEC 4WD</u>	2-15 - -	118	160
<u>HONDA</u>	<u>CR-V IV (RM_)</u>	<u>2.2 i-DTEC AWD (RE6)</u>	10-12 - -	110	150
<u>HONDA</u>	<u>CR-V IV (RM_)</u>	<u>2.4 AWD</u>	1-12 - -	140	190
<u>HONDA</u>	<u>CR-V IV (RM_)</u>	<u>2.4 AWD</u>	9-15 - -	138	188
<u>HONDA</u>	<u>CROSSTOUR</u>	<u>2.4</u>	9-12 - -	143	194
<u>HONDA</u>	<u>CROSSTOUR</u>	<u>3.5 4WD</u>	1-12 - -	202	275
<u>HONDA</u>	<u>CROSSTOUR</u>	<u>3.5 4WD</u>	9-12 - -	207	282
<u>HONDA</u>	<u>ODYSSEY (RL1, RA6, RA_)</u>	<u>3.5</u>	9-05 - -	182	247